

MINI SEALED LED CLEARANCE MARKER LIGHT

Installation:

1. Disconnect the trailer wiring from the towing vehicle.
2. Mark the two mounting screw locations; drill two holes.
3. Mount unit using the screws enclosed.
4. Connect the black lead wire to the tail light circuit.
5. Connect the white lead wire to a grounded location.
6. Check all connections.

Instalacion:

1. Desconecte el cable de remolque de remolque del vehículo.
2. Use la base como guía para marcar dos hoyos para los pernos de montura. Taladra dos hoyos.
3. Conecte base usando pernos.
4. Conecte alambre al circuito (+) positivo de luces en el vehículo.
5. Conecte el alambre blanco del faro a cualquier lugar del remolque donde hagan tierra.
6. Vuelva a conectar los cables del remolque al vehículo remolcador.

Installation:

1. Débrancher le câblage de la remorque du véhicule tracteur.
2. Marquez les emplacements des vis de montage à deux; percer deux trous.
3. Monter l'unité avec les vis fournies.
4. Branchez le câble de fil noir au circuit de feux arrière.
5. Reliez le fil blanc de plomb à un emplacement à la terre.
6. Vérifiez toutes les connexions.