

LED SQUARE STUD-MOUNT CLEARANCE MARKER LIGHT

Installation:

1. Disconnect trailer wiring from towing vehicle.
2. Mount so that no part of vehicle blocks visibility of light.
3. Drill a 3/8" (9.5mm) hole.
4. Insert the black (+) positive lead wire and connect to the headlamp circuit of vehicle (brown wire on boat/utility trailers).
5. Install light using the washer and nut provided.
6. Verify that white wire is properly grounded to vehicle.
7. Reconnect trailer wiring to towing vehicle.

Instalacion:

1. Desconecte el cable de remolque de remolque del vehículo.
2. Ponga en un lugar donde ninguna parte del vehículo bloquea a luz.
3. Taladre hoyo de 3/8" (9.5mm).
4. Meta alambre negro (+) positivo y conecte al circuito de luz en el vehículo (alambre café en tráileres).
5. Instale usando equipo proveído.
6. Verifique que el cable blanco está conectado a tierra correctamente al vehículo.
7. Vuelva a conectar los cables del remolque al vehículo remolcador.

Instalación:

1. cableado del remolque Desconectar del vehículo tractor.
2. Monte para que ninguna parte de los bloques de vehículos visibilidad de la luz.
3. Haga un (9,5mm) Orificio de 3/8".
4. Inserte el cable positivo negro (+) y la conexión al circuito de los faros del vehículo (cable marrón en remolques barco / utilidad).
5. Instale la luz utilizando la arandela y la tuerca suministrada.
6. Verifíez que le fil blanc est correctement mis à la terre véhicule.
7. Vuelva a conectar el cableado del remolque al vehículo tractor.