

# LED SEALED IDENTIFICATION LIGHT BAR

## **Installation:**

1. Disconnect the trailer wiring from the towing vehicle.
2. Center unit on lower rear of trailer and mark the two mounting screw locations. Drill two holes.
3. Mount unit using screws.
4. Attach white wire to a grounded location on the vehicle chassis. Connect the brown lead wire to the tail light circuit using the snap-lock connector provided.
5. Reconnect trailer wiring to towing vehicle.

## **Instalacion:**

1. Desconecte el alambrado para el trailer del carro de remolque.
2. Centree la unidad en la parte inferior del trailer y marque dos hoyos para montarlo. Taladre dos hoyos.
3. Monte la unidad con los tornillos.
4. Conecte el alambre blanco a tierra. Conecte el cable marrón al circuito de luz de la cola utilizando el conector de resorte de bloqueo proporcionado
5. Vuelva a conectar el cableado del remolque al vehículo tractor.

## **Installation:**

1. Débrancher le câblage de la remorque du véhicule tracteur.
2. Unité centrale sur la partie inférieure arrière de la remorque et marquez les deux emplacements de vis de montage. Percez deux trous.
3. Monter l'unité à l'aide de vis.
4. Attacher le fil blanc à un emplacement à la terre sur le châssis du véhicule. Branchez le câble marron au circuit de feux arrière en utilisant le connecteur encliquetage prévu
5. Rebranchez le câblage de la remorque au véhicule de remorquage.