



The Quality Choice

Model: 51951

Submersible Trailer Light Mounting and Connection Instructions

Mount the light with license window on the left rear of the trailer with side marker to the outside of the trailer. Mount the light without license window on the right rear of the trailer with side marker to the outside. Mount the license bracket with the left-hand light. Using metal frame clips, mount each half of the harness down each side of the trailer with yellow and brown wires down left side and green and brown wires down right side. Connect yellow and brown wires to left-hand wire with nut connectors. Connect green and brown harness ends to the right-hand light in the same manner. Attach white ground wire to trailer tongue or frame. Attach wire to brown harness wire with blue wire splitter connectors.

