

LED SEALED STUD MOUNT SIDE MARKER CLEARANCE LIGHT

Installation:

1. Disconnect trailer wiring from towing vehicle.
2. Select mounting place. Mark center of stud hole and second hole in open area beside hole for wire leads.
3. Drill two holes.
4. Pass lead wire through second hole and attach black wire to tail lamp circuit.
5. Insert base stud bolt through center hole.
6. Reconnect trailer wiring to towing vehicle.

Instalacion:

1. Desconecte el cable de remolque de remolque del vehículo.
2. Seleccione lugar donde sera puesto.
3. Taladre dos hoyos.
4. Paso el alambre atravez del segundo hoyo y enganche el alambre negro al circuito de luz.
5. Inserte el perno central por el hoyo y aprete con rosca.
6. Vuelva a conectar los cables del remolque al vehículo remolcador.

Installation:

1. Débrancher le câblage de la remorque du véhicule tracteur.
2. Sélectionnez votre lieu de montage. Marquer le centre du trou goujon et deuxième trou dans la zone ouverte à côté trou pour fils conducteurs.
3. Percez deux trous.
4. Passer fil conducteur à travers deuxième trou et fixez le fil noir au circuit de la lampe de queue. Goujon de base
5. Insérez le goujon de base dans le trou central.
6. Rebranchez le câblage de la remorque au véhicule de remorquage.