

# LED SEALED 3-PIECE IDENTIFICATION LIGHT BAR

## **Installation:**

1. Disconnect the trailer wiring from the towing vehicle.
2. Center unit on lower rear of trailer and mark the two mounting screw locations. Drill two holes.
3. Mount unit using the stainless mounting screws enclosed.
4. Connect the brown lead wire to the tail light (running light) circuit using the snap-lock connector provided.
5. Reconnect trailer wiring to towing vehicle.

## **Instalacion:**

1. Desconecte el alambrado para el trailer del carro de remolque.
2. Centree la unidad en la parte inferior del trailer y marque dos hoyos para montarlo. Taladre dos hoyos.
3. Conecte la unidad usando los pernos.
4. Conecte el cable marrón para la luz trasera (luz corriente) circuito utilizando el conector de resorte de bloqueo proporcionado.
5. Vuelva a conectar el cableado del remolque al vehículo tractor.

## **Installation:**

1. Débrancher le câblage de la remorque du véhicule tracteur.
2. Unité centrale sur la partie inférieure arrière de la remorque et marquez les deux emplacements de vis de montage. Percez deux trous.
3. Monter l'unité à l'aide des vis de fixation inox fermés.
4. Connecter le fil de fil brun à la lumière de queue (running light) circuit en utilisant le connecteur encliquetage fournir.
5. Rebranchez le câblage de la remorque au véhicule de remorquage.