



# LIVEWELL PUMP MANUAL



## **Purpose of this manual:**

The purpose of this manual is to provide necessary information for product installation, operation and maintenance.

**! CAUTION:** Read this manual carefully before installing, using or servicing this product. Failure to follow the instructions within this manual could result in explosion, property damage, severe personal injury and/or death.

## User safety:

General safety rules. These are safety rules that apply:

- Always keep work area clean
- Pay attention to the risks presented by gas and vapors in the work area
- Avoid all electrical dangers. Pay attention to the risks of electric shock or arc flash hazards
- Always bear in mind the risk of drowning, electrical accidents and burn injuries

## Explanation:

1. The fittings are designed as a split quick connect joint, which adopts the split design of lock nut. This solution can quickly disassemble and replace the fitting without dismantling the water pipe which can meet the needs of most users. The lock nut is universal. 1-1/8"29mm 90° fitting sold separately with 360° rotation function to meet any angle requirement.

2. Pump Body 360° rotation function only available for 19463




Rotation Function




19463 Pump Body  
Rotation Function


## Dimensions:



## Wiring Diagram:



## Typical Installation:



## Accessories:



Standard Stright Fitting  
3/4"(19mm) or  
1-1/8"(29mm)



Optional Angle Fitting  
1-1/8"(29mm)